


# Idle Controller Installation (ForkLift)



NOTE: Diagram illustrates bent Wand Switch at idle.

(Swap IGN Feed & GND for straight Wand Switch at idle)